

I 4 11 4: CD 11 C 4:

e-mail: sales@faberkin.com • www.faberkin.com

Installation of Roller Curtains

The roller is a spring loaded – non locking roller.

- 1. Install the shade mounting brackets on the floor directly below the outer side of the table. Bracket should be mounted in such a way as to allow the roller to spin freely.
- 2. The lead edge of the roller curtain has a $1 \frac{1}{2}$ " to 2" pocket which will accept flat bar, which is supplied by the customer. The bar is slid into the pocket and attached to the outside edge of the table.
- 3. Load the spring tension in the roller fasten a vise grip to the square pin on the roller and rotate clockwise approximately ten revolutions. Reinstall roller in brackets. Roller shade should be taunt at all times. If fabric becomes loose, remove roller and turn square pin two or three additional revolutions. Reinstall roller shade. Repeat this step until roller shade maintains tautness at all elevations.